



**2025** STELVIO  
**OWNER HANDBOOK**

# STELVIO

1

INTRODUCTION  
Page 4



2

INTERIOR  
Page 8



3

EXTERIOR  
Page 31



4

EMERGENCY  
Page 37



5

SPECIFICATIONS  
Page 46



6

INDEX  
Page 53

## INTRODUCTION

<b>OWNER HANDBOOK INTRODUCTION</b> .....	4
<b>SYMBOLS KEY</b> .....	4
<b>CUSTOMER ASSISTANCE</b> .....	5
Alfa Romeo Customer Center .....	5
Alfa Romeo Customer Care (Canada) .....	5
Mexico .....	5
Puerto Rico And US Virgin Islands .....	5
Roadside Assistance .....	5
Customer Assistance For The Hearing Or Speech Impaired (TDD/TTY) .....	5
Service Contract .....	6
Warranty Information .....	6
Ordering and Accessing Additional Owner's Information .....	6
Change Of Ownership Or Address .....	7
General Information .....	7

## INTERIOR

<b>INTERIOR OVERVIEW</b> .....	8
<b>STARTING AND OPERATING</b> .....	9
Passive Entry System .....	9
Stop/Start System .....	9
<b>MULTIMEDIA &amp; PHONE CONNECTIVITY</b> .....	10
Information And Entertainment System .....	10
Information And Entertainment Settings .....	10
Pair/Delete A Device .....	11
Apple CarPlay® .....	11
Android Auto™ .....	11
Voice Controls — If Equipped .....	11

Performance Pages — If Equipped .....	12
<b>CHARGING &amp; OUTLETS</b> .....	12
Electrical Power Outlets .....	12
Wireless Phone Charging .....	13
USB .....	14
<b>INSTRUMENT CLUSTER</b> .....	15
Getting To Know Your Instrument Cluster .....	15
Controlling Your Instrument Cluster Display .....	16
Warning Lights And Messages .....	17
Driver Attention Assist (DAA) System .....	17
Traffic Sign Recognition .....	17
<b>INTERIOR COMFORT SETTINGS</b> .....	18
Climate Controls .....	18
Front Heated Seats .....	20
Power Front Seats .....	20
Driver Memory Settings .....	20
Head Restraints .....	21
<b>LIGHTING OPERATION</b> .....	22
Headlight Switch .....	22
Automatic High Beams — If Equipped .....	22
Automatic Headlights .....	22
Automatic Headlights With Wipers .....	22
<b>WINDSHIELD WIPERS &amp; WASHERS</b> .....	23
Windshield Wiper Operation .....	23
Rain Sensing Wipers .....	23
<b>CRUISE CONTROL SYSTEMS</b> .....	24
Adaptive Cruise Control (ACC) .....	24
<b>GARAGE DOOR OPENER (HOMELINK™)</b> .....	26
Troubleshooting Tips .....	27

<b>PARKING ASSISTANCE</b> .....	27
Parksense Front/Rear Park Assist System .....	27
Electric Park Brake (EPB) .....	28
<b>PERFORMANCE FEATURES</b> .....	29
Alfa DNA System .....	29
Alfa Active Suspension (AAS) — If Equipped .....	30

## EXTERIOR

<b>EXTERIOR OVERVIEW</b> .....	31
<b>EXTERIOR CAMERA VIEWS</b> .....	32
Back Up Camera .....	32
<b>HOOD</b> .....	32
To Open The Hood .....	32
Closing The Hood .....	33
<b>LIFTGATE</b> .....	33
Liftgate Release Button .....	33
Hands-Free Liftgate — If Equipped .....	34
<b>REFUELING THE VEHICLE</b> .....	34

## EMERGENCY

<b>SOS AND ASSIST SYSTEM — IF EQUIPPED</b> ...	37
<b>JACKING AND TIRE CHANGING — IF EQUIPPED</b> .....	38
Preparations For Jacking .....	38
Accessing The Jack, Tools, And Spare Tire .....	39
Jacking Instructions .....	39
<b>TIRE SERVICE KIT — IF EQUIPPED</b> .....	41

<b>JUMP STARTING</b> .....	41
Preparations For Jump Starting .....	41
Jump Starting Procedure.....	42
<b>IF YOUR ENGINE OVERHEATS</b> .....	43
<b>TOWING A DISABLED VEHICLE</b> .....	43
Towing In An Emergency.....	44

## SPECIFICATIONS

<b>ENGINE COMPARTMENT OVERVIEW</b> .....	46
2.0L Engine.....	46
<b>FLUID CAPACITIES</b> .....	47
<b>ENGINE FLUIDS AND LUBRICANTS</b> .....	48
<b>CHASSIS FLUIDS AND LUBRICANTS</b> .....	47
<b>SERVICING AND MAINTENANCE</b> .....	50
Scheduled Servicing .....	50
Oil Change Reset .....	52
Engine Break-In Recommendations.....	52
<b>TRAILER TOWING</b> .....	52

## OWNER HANDBOOK INTRODUCTION

Thank you for choosing Alfa Romeo. This Owner Handbook has been prepared to help you quickly become acquainted with important features of your vehicle. It contains most things you will need to operate and maintain your vehicle, including emergency information.

This handbook also illustrates and describes the operation of certain features and equipment that come either standard or optional on your vehicle. It may include a description of features and equipment that your vehicle is not equipped with. FCA US LLC reserves the right to make changes in design and specifications and/or make additions to or improvements to its products without imposing any obligation upon itself to install them on products previously manufactured.

Scan this QR code to access the complete Owner's Manual.



Mobile App:

To access your complete Owner's Manual online: [www.mopar.com](http://www.mopar.com)





To order a hard copy of your Owner's Manual, visit: [www.techauthority.com](http://www.techauthority.com)



TECH  
AUTHORITY

## SYMBOLS KEY

<b>WARNING!</b>	These statements apply to operating procedures that could result in a collision, bodily injury and/or death.
<b>CAUTION!</b>	These statements apply to procedures that could result in damage to your vehicle.
<b>NOTE:</b>	A suggestion which will improve installation, operation, and reliability. If not followed, may result in damage.
<b>TIP:</b>	General ideas/solutions/suggestions on easier use of the product or functionality.
 <b>PAGE REFERENCE ARROW</b>	Follow this reference for additional information on a particular feature.
 <b>FOOTNOTE</b>	Supplementary and relevant information pertaining to the topic.

If you do not read the entire Owner's Manual, you may miss important information. Observe all Cautions and Warnings.

## CUSTOMER ASSISTANCE

FCA US LLC and its authorized dealers are vitally interested in your satisfaction. We want you to be happy with our products and services.

Warranty service must be done by an authorized dealer. We strongly recommend that you take the vehicle to an authorized dealer for non-warranty service as well. FCA US LLC's authorized dealers have the facilities, factory-trained technicians, special tools, and the latest information to ensure the vehicle is fixed correctly and in a timely manner.

If your authorized dealer is unable to resolve the concern, you may contact an FCA US LLC Customer Assistance center.

Any communication to an FCA US LLC Customer Assistance center should include the following information:

- Owner's name and address
- Owner's telephone number (home, mobile, and office)
- Authorized dealer name
- Vehicle Identification Number (VIN)
- Vehicle delivery date and mileage

## ALFA ROMEO CUSTOMER CENTER

P.O. Box 21-8004  
Auburn Hills, MI 48321-8004  
Phone: 1-844-Alfa-USA (1-844-253-2872)

## ALFA ROMEO CUSTOMER CARE (CANADA)

P.O. Box 1621  
Windsor, Ontario N9A 4H6  
Phone: (800) 465-2001 English / (800) 387-9983 French

## MEXICO

Av. Prolongacion Paseo de la Reforma, 1240  
Sante Fe C.P. 05109  
Mexico, D.F.  
In Mexico City: 800-505-1300  
Outside Mexico City: +(52) 55 50817568

## PUERTO RICO AND US VIRGIN ISLANDS

FCA Caribbean LLC  
P.O. Box 191857  
San Juan 00919-1857  
Phone: 1-844-Alfa-USA (1-844-253-2872)

## ROADSIDE ASSISTANCE

**Available 24 hours, 7 days a week.**

Call 1-855-299-1368 or visit [alfaromeo.rsahelp.com](http://alfaromeo.rsahelp.com) (USA)

Call 1-800-363-4869 or visit [fca.roadsideaid.com](http://fca.roadsideaid.com) (Canada)

Your vehicle's VIN number is required to receive covered services.

- Flat Tire Service
- Out Of Gas/Fuel Delivery - This service is limited to two occurrences in a 12-month period. Up to two gallons of fuel will be provided by a service provider.
- Battery Jump Assistance
- Lockout Service
- Towing Service

## CUSTOMER ASSISTANCE FOR THE HEARING OR SPEECH IMPAIRED (TDD/TTY)

To assist customers who have hearing difficulties, FCA US LLC has installed special Telecommunication Devices for the Deaf (TDD) equipment at its customer centers. Any hearing or speech impaired customer, who has access to a TDD or a conventional teletypewriter (TTY) in

the United States, can communicate with FCA US LLC by dialing 1-800-380-2479.

Canadian residents with hearing difficulties who require assistance can use the special needs relay service offered by Bell Canada. For TTY users, dial 711. For Voice callers, dial 1-800-855-0511 to connect with a Bell Relay Service operator.

## SERVICE CONTRACT

You may have purchased a service contract for a vehicle to help protect you from the high cost of unexpected repairs after FCA US LLC's New Vehicle Limited Warranty expires. The Mopar® Vehicle Protection plans are the ONLY vehicle extended protection plans authorized, endorsed and backed by FCA US LLC to provide additional protection beyond your vehicle's warranty. If you purchased a Mopar® Vehicle Protection Plan, you will receive Plan Provisions and an Owner Identification Card in the mail within three weeks of the vehicle delivery date. If you have any questions about the service contract, call FCA US LLC's Service Contract National Customer Hotline at 1-800-521-9922 (Canadian residents, call (800) 465-2001 English / (800) 387-9983 French).

Mopar Vehicle Protection Plans offer valuable protection against repair costs after your vehicle warranties have expired. Mopar Vehicle Protection plans are the ONLY vehicle extended

protection plans authorized, endorsed and backed by FCA US LLC to provide additional protection beyond your vehicle's warranty.

FCA US LLC is not responsible for any service contract you may have purchased from another manufacturer. If you require service after the FCA US LLC New Vehicle Limited Warranty expires, please refer to the contract documents, and contact the person listed in those documents.

You may have purchased additional coverage with an extended service contract. FCA Canada Inc. stands fully behind its service contracts. Be sure that the one you buy is a genuine Canada Inc. service contract. We are not responsible for other companies' contracts. If you purchased a contract other than a genuine FCA Canada Inc. service contract and you have a problem, you will have to contact the administrator of that contract for resolution. If you have any questions about the service contract, call the FCA's Service Contract National Customer Hotline at (800) 465-2001 English / (800) 387-9983 French).

## WARRANTY INFORMATION

Scan this QR code to learn more about warranty information.

Refer to [www.owners.mopar.ca/fr](http://www.owners.mopar.ca/fr) for further information.



## ORDERING AND ACCESSING ADDITIONAL OWNER'S INFORMATION

To order the following manuals, you may use either the website or the phone numbers listed below.

### Service Manuals

These comprehensive Service Manuals provide a complete working knowledge of the vehicle, system, and/or components and is written in straightforward language with illustrations, diagrams, and charts.

### Diagnostic Procedure Manuals

Diagnostic Procedure Manuals are filled with diagrams, charts and detailed illustrations. These manuals make it easy to find and fix problems on computer-controlled vehicle systems and features. They show exactly how to find and correct problems, using step-by-step troubleshooting and drivability procedures, proven diagnostic tests and a complete list of all tools and equipment.

To order a digital copy of your Service or Diagnostic Procedure manuals, visit:

[www.techauthority.com](http://www.techauthority.com) (US and Canada).

## Owner's Manuals

These Owner's Manuals have been prepared with the assistance of service and engineering specialists to acquaint you with specific FCA vehicles.

To access your Owner's Information online, visit [www.mopar.com/om](http://www.mopar.com/om) (US) or [www.owners.mopar.ca](http://www.owners.mopar.ca) (Canada).

Or visit:

[www.techauthority.com](http://www.techauthority.com) to order physical copies of Owner's Manuals (US).

Owner's Manuals, Radio Manuals and Warranty Information Books can be ordered through Archway at:

**1-800-387-1143 (Canada)**

## CHANGE OF OWNERSHIP OR ADDRESS

\*If you have purchased this vehicle used or have changed your address, please provide the following information and mail to:

### FCA US LLC

P.O. Box 21-8008

Auburn Hills, MI 48321-8004

Make sure to include the following:

- Date of Sale (mm/dd/yy)
- Vehicle Identification Number (17 Character ID located on top left of the instrument panel)
- Exact Odometer Reading
- First and Last Name
- Phone Number
- Street Address, City, State and Zip Code
- Email Address

\*Applies to US residents only.

## GENERAL INFORMATION

The following regulatory statement applies to all Radio Frequency (RF) devices equipped in this vehicle:

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Innovation, Science and Economic Development applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage, et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

La operación de este equipo está sujeta a las siguientes dos condiciones:

1. es posible que este equipo o dispositivo no cause interferencia perjudicial y
2. este equipo o dispositivo debe aceptar cualquier interferencia, incluyendo la que pueda causar su operación no deseada.

### NOTE:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## INTERIOR OVERVIEW



1 – Garage Door Opener (HomeLink®) ⇨ page 26

2 – Assist & SOS Buttons ⇨ page 37

3 – Cruise Control Buttons ⇨ page 24

4 – Instrument Cluster Display ⇨ page 15

5 – Instrument Cluster Controls ⇨ page 16

6 – Windshield Wipers and Washers ⇨ page 23

7 – Information and Entertainment System ⇨  
page 10

8 – Stop/Start Off Switch ⇨ page 9

9 – Headlight Switch ⇨ page 22

10 – Voice Commands ⇨ page 11

11 – Climate Controls ⇨ page 18

12 – USB Media Hub ⇨ page 14

13 – Electric Park Brake ⇨ page 28

14 – Alfa DNA System Selector ⇨  
page 29

## STARTING AND OPERATING

### PASSIVE ENTRY SYSTEM

Scan this QR code to learn more about the passive entry system.




Passive Entry allows you to lock and unlock the vehicle's door(s) without having to push the key fob lock or unlock buttons.

#### To Unlock/Lock The Vehicle's Doors And Liftgate

With a valid Passive Entry key fob with you, grab the handle to unlock the vehicle. The driver's handle will unlock the driver's door only (unless otherwise programmed in radio settings), whereas the passenger handle will unlock all doors and the liftgate.

With a valid Passive Entry key fob on you, push the Passive Entry lock button on the door handle to lock the vehicle.



#### Push The Door Handle Button To Lock

#### NOTE:

- DO NOT grab the door handle when pushing the lock button. This could unlock the door(s).
- Be sure to keep the vehicle key fob with you.

### STOP/START SYSTEM

Scan this QR code to learn more about the stop/start system.



The Stop/Start function is designed to save fuel and reduce emissions. The system will stop the engine automatically during a vehicle stop if the required conditions are met. Releasing the brake

pedal or shifting out of DRIVE will automatically restart the engine.

### How To Turn Off The Stop/Start System

Did you know you can manually turn off your Stop/Start system?



#### Stop/Start Button


To manually activate/deactivate the system, push the button located on the control panel to the left of the steering wheel.

#### NOTE:

The Stop/Start system will reset itself back to the on position every time the ignition is turned off and back on.

## MULTIMEDIA & PHONE CONNECTIVITY

### INFORMATION AND ENTERTAINMENT SYSTEM



#### Information And Entertainment System

- 1 — Status Bar
- 2 — Compartment Reorder Graphic Button
- 3 — Enlarge Graphic Button
- 4 — Temperature Inside Passenger
- 5 — Widget Buttons

#### NOTE:

Information and Entertainment screen images may not reflect the exact software in this vehicle.

### INFORMATION AND ENTERTAINMENT SETTINGS

Scan this QR code to learn more about Information and Entertainment Settings.



The Settings menu can be activated by using the appropriate Settings widget on the Main menu.

#### NOTE:

Depending on the vehicle's options, feature settings may vary.




#### Information And Entertainment System Settings

- **Lights** — Customize features such as “Headlight Sensitivity” and “Headlight Off Delay” and much more.

- **Units & Language** — Customize the Units and Language used in the vehicle.
- **Clock & Date** — Customize the date and time.
- **Passive Safety** — Customize the passive safety functions.
- **Driver Comfort** — Set the “Easy Entry” and “Passive Entry” for added convenience.
- **Doors & Locks** — Customize settings related to the vehicle's door, horn, and liftgate.
- **Cluster** — Customize and view trip, phone, audio, navigation, speed, and more from your instrument cluster.
- **Infotainment** — The Infotainment setting allows you to edit audio settings, home page layout, Bluetooth®, entertainment parameters, and more!
- **System** — Customize updates regarding the radio.

### PAIR/DELETE A DEVICE



#### Information And Entertainment Phone Mode

Scan this QR code to learn more about Pairing a Device.



1. Activate the Bluetooth® function on the device.
2. From the Main menu, select the "SETTINGS" function by turning and pushing the Rotary Pad.
3. Select "Infotainment".
4. Select the Bluetooth® device.
5. Select "Add device".
6. Search for the radio system on the Bluetooth® audio device (during the pairing stage a screen is displayed showing the progress of the operation).
7. Select the device to be paired.
8. When requested by the audio device, enter the PIN shown on the system display or confirm on the device the PIN displayed.
9. When the pairing procedure is completed successfully, a dedicated screen is displayed.

Once the phone or device is paired to the system via Bluetooth®, the Priority Device menu will appear on the display allowing you to give priority to the pairing connection of the selected device over the other paired devices.

## APPLE CARPLAY®

1. Ensure that your iPhone® is unlocked for the very first connection, then ensure Siri is enabled in settings.
2. Connect your iPhone® to one of the media USB ports in the vehicle, or pair your iPhone® with the system. You have no need to plug your device in if it is paired with the system.
3. Once the device is connected and recognized, the Phone icon on the menu bar changes to the Apple CarPlay® icon.

### NOTE:

To use Apple CarPlay®, make sure that cellular data is turned on, and that you are in an area with cellular coverage. Your data and cellular coverage is shown on the left side of the touchscreen within Apple CarPlay®. Data plan rates may apply.

## ANDROID AUTO™

1. Download the Android Auto™ app from the Google Play store.
2. Connect your phone to one of the media USB ports in the vehicle, or pair your phone with the system. You have no need to plug your device in if it is paired with the system.

3. Once the device is connected and recognized, the Phone icon on the menu bar changes to the Android Auto™ icon.

### NOTE:

To use Android Auto™, make sure you are in an area with cellular coverage. Android Auto™ may use cellular data, and your cellular coverage is shown in the upper right corner of the touchscreen. Data plan rates may apply.

## VOICE CONTROLS — IF EQUIPPED

### Introduction

Scan this QR code to learn more about Voice Controls.



Start using Voice Recognition with these helpful quick tips. They provide the key voice controls and tips you need to know to handle the vehicle's voice control system.

### Basic Voice Controls

The following basic voice controls can be given at any point while using your Information and Entertainment system.


To activate the voice system, push the related button on the steering wheel.

After a voice session has been opened, the system shows its status through an icon on the display and an acoustic signal.

Voice controls can be used for most functions of the main applications of the radio system ("RADIO", "MEDIA", "NAVIGATION", and "PHONE").

## PERFORMANCE PAGES — IF EQUIPPED

Performance Pages is an application that provides a display of performance indicators that will help you gain familiarity with the capabilities of the vehicle in real time.



### Performance Pages

The following information is shown on the main screen of the "Performance Pages":

- "Technical gauges"

- "Consumption history"
- "Efficient Drive"
- "AWD/Engine torque"
- "Torque" (if equipped)
- "Performance content" (if equipped)
- "AWD (All Wheel Drive)" (if equipped)

Turn the Rotary Pad to select the desired item and then push the Rotary Pad to confirm the selection and access the menu or, using the touchscreen function, touch the display to select the desired items.

## CHARGING & OUTLETS

### ELECTRICAL POWER OUTLETS

The Instrument Panel Power Outlet is located on the center stack under the climate controls. It will only operate when the ignition is in the ON/RUN position.

This vehicle might have an outlet in any of the following locations:

- On the center stack under the climate controls
- On the left side of the luggage compartment
- On the bottom of the center stack, in front of the cupholders



Instrument Panel Power Outlet



Luggage Compartment Power Outlet — If Equipped

**NOTE:**

- For the Instrument Panel Power Outlet, do not connect any of your devices that have a power rating higher than 180 W, for the Luggage Compartment Power Outlet and the Center Console Power Inverter do not connect any of your devices that have a power rating higher than 150 W. Do not use power adapters that do not fit the outlet as this may damage it.
- Power outlets labeled with a key symbol are powered when the ignition is in the ON/RUN position.

**WARNING!**

If this outlet is misused, it may cause an electric shock and failure. To avoid serious injury or death:

- Only devices designed for use in this type of outlet should be inserted into any 12 Volt outlet.
- Do not touch with wet hands.
- Close the lid when not in use and while driving the vehicle.

**CAUTION!**

- Power outlets are designed for accessory plugs only. Do not insert any other object in the power outlets as this will damage the outlet and blow the fuse. Improper use of the power outlet can cause damage not covered by your New Vehicle Limited Warranty.
- Many accessories that can be plugged in draw power from the vehicle's battery, even when not in use (i.e., cellular phones, etc.). Eventually, if plugged in long enough, the vehicle's battery will discharge sufficiently to degrade battery life and/or prevent the engine from starting.
- Accessories that draw higher power (i.e., coolers, vacuum cleaners, lights, etc.), will discharge the battery even more quickly. Only use these intermittently and with greater caution.
- After the use of high power draw accessories, or long periods of the vehicle not being started (with accessories still plugged in), the vehicle must be driven a sufficient length of time to allow the generator to recharge the vehicle's battery.

**WIRELESS PHONE CHARGING**

Scan this QR code to learn more about the wireless charging pad.



The vehicle may be equipped with a wireless charging pad located below the center stack, within the storage compartment. It is designed to easily charge your Qi® enabled mobile phone on the go.

**Wireless Charging Pad**

The wireless charging pad may include an anti-slip mat to hold your mobile phone in place and an indicator light that indicates your phone is charging.

Be sure to place your mobile device on the center of the charging pad, with the display facing upward, and your device not covering the LED.

#### LED Indicator Status:

- No Light: Charging pad is idle or searching for a device.
- Blue Light: Device is detected, and is charging.
- Red Light/Flashing: Internal error, or foreign object is detected.
- Green Light: Device has completed battery charging (if device is equipped to transmit this information).

#### NOTE:

- Do not place the key fob on or near the charging pad.
- Using a phone case may interfere with wireless charging.


#### CAUTION!

The key fob should not be placed on the charging pad or within 6 inches (15 cm) of it. Doing so can cause excessive heat buildup and damage to the fob. Placing the fob in close proximity of the charging pad blocks the fob from being detected by the vehicle and prevents the vehicle from starting.


## USB

This vehicle is equipped with:


- One USB port located in the center of the dashboard
- Two USB ports located in the center console storage compartment between the front seats. To access the center console storage, push the button under the front of the armrest to raise the cover
- Two USB ports located in the rear of the center console storage compartment



Center Console USB Ports



Dashboard USB Port



Rear Center Console USB Ports

## INSTRUMENT CLUSTER

### GETTING TO KNOW YOUR INSTRUMENT CLUSTER




Scan this QR code to learn more about the instrument cluster.



#### NOTE:

Depending on your vehicle trim, your instrument cluster display may vary.

1. Speedometer
  - Indicates vehicle speed.
2. Instrument Cluster Display
  - When the appropriate conditions exist, this display shows the instrument cluster display messages.
  - The display always shows one of the main menu items after ignition is placed on.
3. Tachometer
  - Indicates the engine speed in revolutions per minute (RPM x 100).
4. Fuel Gauge
  - The gauge shows the level of fuel in the fuel tank when the Keyless Push Button Ignition is in the ON/RUN position.


-  The fuel pump symbol points to the side of the vehicle where the fuel door is located.

5. Oil Temperature Gauge
  - The temperature gauge shows engine oil temperature. Any reading within the normal range indicates that the engine is operating satisfactorily.

## CONTROLLING YOUR INSTRUMENT CLUSTER DISPLAY

The instrument cluster display features a driver interactive display that is located in the instrument cluster.

The systems allow the driver to select information by using the thumbwheel, mounted on the steering wheel:



Instrument Cluster Display Controls

- **Thumbwheel**  
Use the **Thumbwheel** on the right side of the steering wheel to scroll through the menu options and submenus in the Instrument Cluster Display.
- **Thumbwheel Button**  
Press the **Thumbwheel Button** to select the highlighted menu option.
- **Main Screen Button**  
Press the **Main Screen Button** button for the Main Screen display. The Main Screen button toggles between controlling the radio, Main Screen on the instrument cluster, and the widget on the right side of the instrument cluster display.

## Main Screen Configuration — If Equipped

- Navigate **up** ▲ or **down** ▼ to highlight desired Tile.
- Press **Thumbwheel** to select the tile and navigate to the selected submenu and press **Thumbwheel** again to add your selection to your tile view.
- The **Main Screen** options are Speedometer, Performance, Driver Assist, and Stored Messages.

## Cluster Display Layouts

Push the Menu View button on the windshield wiper stalk to change the cluster layout.



Instrument Cluster Menu View Button

## Cluster Display Layout Selections

- **Evolved Layout** — Gauges are displayed in a more compact fashion.
- **Relax Layout**— Gauges are hidden, less information is displayed. All main screens and widgets are available.
- **Heritage Layout** — Full sized round gauges are visible, main screens and widgets are available.

## WARNING LIGHTS AND MESSAGES

Warning lights, indicators, and messages appear to signify various vehicle conditions. See the Quick Start Guide or Owner's Manual for examples and detailed descriptions. Some telltales are optional according to vehicle equipment.

## DRIVER ATTENTION ASSIST (DAA) SYSTEM



The Driver Attention Assist (DAA) system detects when the driver is feeling fatigued and warns the driver to pull over and take a break.

The DAA system can be activated and deactivated through the radio system by selecting the following in order: "Driver Assistance", "Driver Attention Assist".

If the driver accepts the suggestion provided by the system by pushing the MENU button on the multifunction lever, the message will disappear from the display and the symbol will be displayed in the dedicated area of the instrument cluster display until the next engine shutdown.

If the driver ignores the warning provided by the system and does not stop, the message will continue to remain on the display, along with the symbol.

### WARNING!

The DAA system is an aid for driving and does not relieve the driver of the responsibility of driving the vehicle. If you experience fatigue while driving, pull over safely for a break without waiting for the DAA warnings. Only return to the road when you are in the right physical and mental condition to prevent endangering yourself and other drivers.

## TRAFFIC SIGN RECOGNITION

Your Traffic Sign Recognition (TSR) system uses a camera mounted on the windshield, as well as map data (if your vehicle is equipped with Navigation) to detect recognizable road signs such as:

- Speed limits

- No passing zones
- Signs indicating the end of speed limit or no passing zones

The system always checks the traffic signs indicating the current speed limit signs. The system is able to recognize and display up to two different road signs in the instrument cluster display.

**NOTE:**

The TSR System can be activated/deactivated in the radio system in the Driver Assistance menu. The system activation is signaled by road signs shown on the instrument cluster display.

**CAUTION!**

- Functionality may be limited or the system may not work if the sensor is obstructed.
- The system may have limited operation or not work at all in weather conditions such as heavy rain, hail, and thick fog. Strong light contrasts can influence the recognition capability of the sensor.
- The area surrounding the sensor must not be covered with stickers or any other object.
- Do not tamper or perform any operations in the area of the windshield glass directly surrounding the sensor.

*(Continued)*

**CAUTION!**

- Clean foreign matters such as bird droppings, insects, snow or ice on the windshield. Use specific detergents and clean cloths to avoid scratching the windshield.

## INTERIOR COMFORT SETTINGS

### CLIMATE CONTROLS



**Automatic Climate Controls**

Scan this QR code to learn more about the Climate Control Systems.



The Climate Control system allows you to regulate the temperature, air flow, and direction of air circulating throughout the vehicle.

**CAUTION!**

The system uses R1234yf refrigerant, which does not pollute the environment in the event of accidental leakage. Under no circumstances, use R134a and R12 fluids, which are incompatible with the components of this system.

### A/C Compressor

Push the A/C button or the icon to activate or deactivate the A/C compressor (indicator illuminated when activated). The A/C compressor will remain off even after the engine has stopped.

When the A/C compressor is turned off, the system deactivates air recirculation to prevent the windows from fogging up. If the climate control system can maintain the temperature, with the A/C turned off, the AUTO feature will

remain on and the AUTO button indicator light will not switch off.

To restore automatic control of the A/C compressor, push the A/C button or the AUTO button. With the A/C compressor off, the air speed can be set manually using the Air Speed Adjustment Knob.

When the A/C compressor is on, and the engine is running, air speed cannot be lower than the minimum speed (only one indicator light is lit).

**NOTE:**

When the A/C is off, the Climate Control system can not produce air that is colder than the current outside temperature. Under certain environmental conditions, windows could fog up rapidly, since the air is not dehumidified.

## Air Recirculation Button



Push the button to change the system between Recirculation mode and outside air mode.

## Front Defrost



Push the button to change the current airflow setting to Defrost mode.

## Rear Defrost



Push the button to turn on the rear window defroster and heated mirrors.

### CAUTION!

Failure to follow these cautions can cause damage to the heating elements:

- Use care when washing the inside of the rear window. Do not use abrasive window cleaners on the interior surface of the window. Use a soft cloth and a mild washing solution, wiping parallel to the heating elements. Labels can be peeled off after soaking with warm water.
- Do not use scrapers, sharp instruments, or abrasive window cleaners on the interior surface of the window.
- Keep all objects a safe distance from the window.

## Front Defrost And MAX-DEF Function



Push the MAX-DEF button (indicator illuminated) to defrost the windshield and side windows.

## AUTO Button



Push the button after setting your desired temperature and the system will maintain the set temperature.

## SYNC Button



Press the SYNC button on the touchscreen to synchronize the driver and front passenger temperature settings.

## Blower Speed

Use the small or large blower icon toggle switches or the blower bar on the touchscreen to increase or decrease the amount of air forced through the climate control system.

## Air Distribution Selection

Push the Air Distribution Selection button on the faceplate to change the mode of air distribution.

**NOTE:**

In AUTO mode, the Climate Controls automatically manage the air distribution. When set manually, the respective symbols on the radio system indicate the air distribution setting.

## Mode Control

Select Mode by pressing one of the Mode buttons on the touchscreen, or the faceplate, to change the airflow distribution mode.

## Front Defrost And Panel Mode

Air flow is distributed between the windshield demisting/defrosting vents and side/central dashboard vents. This setting allows air to flow to the windshield on sunny days.

## Front Defrost And Bi-Level Mode

Air flow is distributed to all vents.

## Switching The Climate Control System Off

Press the button to turn the climate control system off.

## FRONT HEATED SEATS



Press the heated seat button to cycle through Maximum, Medium, Minimum, and off settings.

### WARNING!

- Persons who are unable to feel pain to the skin because of advanced age, chronic illness, diabetes, spinal cord injury, medication, alcohol use, exhaustion or other physical condition must exercise care when using the seat heater. It may cause burns even at low temperatures, especially if used for long periods of time.
- Do not place anything on the seat or seatback that insulates against heat, such as a blanket or cushion. This may cause the seat heater to overheat. Sitting in a seat that has been overheated could cause serious burns due to the increased surface temperature of the seat.

## POWER FRONT SEATS

There are two power seat switches that are used to control the movement of the seat cushion and the seatback.

Push the power lumbar switch forward to increase the lumbar support. Push the switch rearward to decrease the lumbar support. Pushing upward or downward on the switch will raise and lower the position of the support.



### Power Seat Switches

- 1 — Power Seat Cushion Switch
- 2 — Power Seatback Switch
- 3 — Power Lumbar Switch

### WARNING!

Do not ride with the seatback reclined so that the shoulder belt is no longer resting against your chest. In a collision you could slide under the seat belt, which could result in serious injury or death.

## DRIVER MEMORY SETTINGS

This feature allows you to save up to three different memory profiles for easy recalling through a memory switch. Each memory profile saves your desired position settings for the following features:

- Driver's seat
- Side mirrors



### Memory Seat Buttons

To recall the memory settings, push the desired memory button number (1, 2, or 3).

### Programming the Memory Feature

1. Place the ignition in the ON/RUN position (do not start the engine).
2. Adjust all memory profile settings to desired preferences (i.e., seat and side mirror positions).
3. Push and hold the memory button you want to program for 1.5 seconds. A chime will sound to indicate that the memory profile has been saved successfully.

## HEAD RESTRAINTS

Did you know your vehicle is equipped with front driver and passenger head restraints that can be adjusted two different ways?

Head restraints are designed to reduce the risk of injury by restricting head movement in the event of a rear impact. Head restraints should be adjusted so that the top of the head restraint is located above the top of your ear.

To raise the head restraint, pull up on the head restraint until it clicks into place.

To lower the head restraint, push in the adjustment button and lower the head restraint to the desired height while holding the button. Then, release the adjustment button.



### Front Head Restraint

- 1 — Adjustment Button
- 2 — Release Button



### Rear Head Restraint

- 1 — Adjustment Button
- 2 — Release Button

For upward adjustment, pull up on the head restraint until it clicks into place. For downward adjustment, push in the adjustment button and lower the head restraint while holding the button to the desired height.

To remove adjustable head restraints, proceed as follows:

- Raise the head restraints to their maximum height.
- Push the adjustment button and the release button at the side of the two supports.

- Remove the head restraints by pulling them upwards.

### WARNING!

- All occupants, including the driver, should not operate a vehicle or sit in a vehicle's seat until the head restraints are placed in their proper positions in order to minimize the risk of neck injury in the event of a crash.
- Head restraints should never be adjusted while the vehicle is in motion. Driving a vehicle with the head restraints improperly adjusted or removed could cause serious injury or death in the event of a collision.

### Sparco Racing Seat Head Restraints (Quadrifoglio Vehicles) — If Equipped

Head restraints on Sparco Racing Seats (front seats) are non-adjustable and non-removable.

## LIGHTING OPERATION

### HEADLIGHT SWITCH

The headlight switch is located on the left side of the instrument panel and is used to control your lighting.



Headlight Switch

- 1 — ParkSense Button
- 2 — Headlight Control Switch
- 3 — Instrument Panel Dimmer
- 4 — Rear Fog Light Button
- 5 — Engine Stop/Start Button

Rotate the headlight control knob to select one of the available positions: O (off), AUTO headlights, parking lights, and headlights on.

### AUTOMATIC HIGH BEAMS — IF EQUIPPED

Did you know your vehicle can automatically switch from high beams to low beams until an approaching vehicle is out of view?

To turn on this feature:

- Within the radio system, set "Auto Dim High Beams" to "ON".
- Place the headlight switch in the AUTO position.
- Push the multifunction lever forward to activate the high beams.

### AUTOMATIC HEADLIGHTS

With the engine running, make sure your headlight control knob is in the AUTO position; your vehicle will detect how bright it is outside and turn the headlights on/off as necessary.

### AUTOMATIC HEADLIGHTS WITH WIPERS

You can have your automatic headlights automatically turn on when the wiper system is on, provided that your headlights are in AUTO mode and the engine is running. You can turn this feature on/off in the radio settings.

If you have Rain Sensing Wipers, and they are on, the headlights will automatically turn on after the wipers complete five wipe cycles within approximately one minute.

## WINDSHIELD WIPERS & WASHERS

Scan this QR code to learn more about wipers & washers.



The windshield wiper/washer controls are located on the windshield wiper/washer lever on the right side of the steering column. The front wipers are operated by rotating a switch, located on the end of the lever.



Windshield Wiper/Washer Lever

## WINDSHIELD WIPER OPERATION

### Front Wipers

Rotate the switch to the Low Continuous Wiper Speed position to activate the first (low) level continuous speed of the windshield wipers in manual mode.

Rotate the switch to the High Continuous Wiper Speed position to activate the second (high) level continuous speed of the windshield wipers in manual mode.

### Windshield Washers

To use the washer, pull the windshield wiper lever toward the steering wheel and hold.

### Mist

Push the lever upward to the MIST position and release for a single wiping cycle.

### NOTE:

The mist feature does not activate the washer pump; therefore, no washer fluid will be sprayed on the windshield. The washer function must be used in order to spray the windshield with washer fluid.

### Rear Wiper

Push the windshield wiper lever downward (without the vehicle in REVERSE) to activate/deactivate intermittent rear wiper operation.

## WARNING!

Sudden loss of visibility through the windshield could lead to a collision. You might not see other vehicles or other obstacles. To avoid sudden icing of the windshield during freezing weather, warm the windshield with the defroster before and during windshield washer use.

## CAUTION!

Always remove any buildup of snow that prevents the windshield wiper blades from returning to the parked position. If the windshield wiper switch is turned off, and the blades cannot return to the parked position, damage to the wiper motor may occur.

## RAIN SENSING WIPERS

This feature senses rain or snowfall on the windshield and automatically activates the wipers.

The activation of the rain sensor system is done by tapping the wiper stalk upwards while the switch is in the Low Sensitivity Rain Sensing position (2) or High Sensitivity Rain Sensing position (1).



**Windshield Wiper Stalk**

- 1 — High Sensitivity Rain Sensing position
- 2 — Low Sensitivity Rain Sensing position

## CRUISE CONTROL SYSTEMS

Scan this QR code to learn more about the cruise control systems.



Your vehicle is equipped with the Adaptive Cruise Control (ACC) system. ACC will adjust the vehicle speed up to the preset speed to maintain a distance with the vehicle ahead.

### NOTE:

If Active Speed Limiter is enabled, Adaptive Cruise Control will be unavailable, and vice versa.

## ADAPTIVE CRUISE CONTROL (ACC)

### WARNING!

- Adaptive Cruise Control (ACC) is a convenience system. It is not a substitute for active driver involvement. It is always the driver's responsibility to be attentive of road, traffic, and weather conditions, vehicle speed, distance to the vehicle ahead and, most importantly, brake operation to ensure safe operation of the vehicle under all road conditions. Your complete attention is always required while driving to maintain safe control of your vehicle. Failure to follow these warnings can result in a collision and death or serious personal injury.
- The ACC system:
  - Does not react to pedestrians, oncoming vehicles, and stationary objects (e.g., a stopped vehicle in a traffic jam or a disabled vehicle).
  - Cannot take street, traffic, and weather conditions into account, and may be limited upon adverse sight distance conditions.

*(Continued)*

### WARNING!

- Does not always fully recognize complex driving conditions, which can result in wrong or missing distance warnings.
- Will bring the vehicle to a complete stop while following a vehicle ahead and hold the vehicle for approximately two minutes in the stop position. If the vehicle ahead does not start moving within two minutes, the parking brake will be activated and the ACC system will be canceled.

You should switch off the ACC system:

- When driving in fog, heavy rain, heavy snow, sleet, heavy traffic, and complex driving situations (i.e., in highway construction zones).
- When entering a turn lane or highway off-ramp; when driving on roads that are winding, icy, snow-covered, slippery, or have steep uphill or downhill slopes.
- When circumstances do not allow safe driving at a constant speed.

The buttons on the left side of the steering wheel operate the ACC system.



Adaptive Cruise Control Buttons

- 1 — Distance Button
- 2 — RES/Set Switch
- 3 — On/Off Button

#### ● To Activate/Deactivate

- Push and release the on/off button.

#### WARNING!

Leaving the Adaptive Cruise Control (ACC) system on when not in use is dangerous. You could accidentally set the system or cause it to go faster than you want. You could lose control and have a collision. Always leave the system off when you are not using it.

#### ● To Set A Desired ACC Speed

- When the vehicle has reached the desired speed, push the RES/SET switch up or down briefly, then release.

#### WARNING!

If the Active Speed Limiter is active, the system will not react to vehicles ahead. In addition, the proximity warning does not activate and no alarm will sound even if you are too close to the vehicle ahead since neither the presence of the vehicle ahead nor the vehicle-to-vehicle distance is detected. Be sure to maintain a safe distance between your vehicle and the vehicle ahead. Always be aware which mode is selected.

#### ● To Deactivate

- You can deactivate the ACC by pressing the on/off button again, placing your vehicle's ignition in the OFF position or by activating RACE mode (Quadrifoglio models).

#### ● To Resume Speed

- If ACC was canceled, and there is a set speed in memory, push the RES/SET switch upward.

#### WARNING!

The Resume function should only be used if traffic and road conditions permit. Resuming a set speed that is too high or too low for prevailing traffic and road conditions could cause the vehicle to accelerate or decelerate too sharply for safe operation. Failure to follow these warnings can result in a collision and death or serious personal injury.

#### ● To Vary The Speed Setting

- Once the vehicle speed has been set, you can increase the speed by pushing the RES/SET switch upward or decrease the speed by pushing the RES/SET switch downward.

#### ● Setting The Following Distance In ACC

- To decrease the distance setting, push the Distance Setting Button and release. Each time the button is pushed, the distance setting increases by one bar (longer). Once the longest setting is reached, if the button is pushed again it will be set to the shortest setting available.

## WARNING!

- The maximum braking applied by the system is limited. The driver may apply the brakes in all cases if needed.
- If the system predicts that the braking level is insufficient to hold the set distance, either "BRAKE!" or a dedicated message is displayed to warn the driver of approaching the vehicle ahead. An acoustic signal is also emitted. In this case, it is advised to brake immediately as necessary to hold a safe distance from the vehicle ahead.
- The driver is responsible for ensuring that there are no pedestrians, other vehicles or objects along the direction of the vehicle. Failure to comply with these precautions may cause serious accidents and injuries.
- The driver is fully responsible for holding a safe distance from the vehicle ahead respecting the highway code in force in the respective country.

## GARAGE DOOR OPENER (HOMELINK®)

Scan this QR code to learn more about HomeLink® (Garage Door Opener).



The HomeLink® buttons are located in the overhead console or sun visor and contain three optional HomeLink® channels.



HomeLink® Buttons

- **TO ERASE ALL SET CHANNELS:** Push and hold the two outside HomeLink® buttons for 20 seconds until the indicator flashes above the buttons.

- **ROLLING OR NON-ROLLING?** Check your garage door opener motor in your garage for a "LEARN" or "TRAIN" button by the hanging antenna. If you have one of these, you have a Rolling Code garage door opener.

1. While the car is ON, hold the handheld garage door transmitter 1-3 inches from the HomeLink® button you want to program in the vehicle.
2. Push and hold both the HomeLink® button being programmed and the button on the garage door transmitter.
3. **For Non-Rolling Code** garage door openers, watch for the indicator light to stay illuminated.

**For Rolling Code** garage door openers, watch for the indicator light to go from a slow blink to blinking rapidly.

4. **For Rolling Code** garage door openers only, firmly push and release the "LEARN" or "TRAIN" button on your garage door opener motor in your garage, then push the HomeLink® button in your vehicle three times (holding the button for two seconds each time).

### WARNING!

- Your motorized door or gate will open and close while you are programming the universal transmitter. Do not program the transmitter if people or pets are in the path of the door or gate.
- Do not run your vehicle in a closed garage or confined area while programming the transmitter. Exhaust gas from your vehicle contains carbon monoxide (CO) which is odorless and colorless. Carbon monoxide is poisonous when inhaled and can cause you and others to be severely injured or killed.



If you have any problems, or require additional assistance, please call toll-free 1-800-355-3515 or visit HomeLink.com.

### NOTE:

If the programming was successful, your garage door should open and close with your chosen HomeLink® button.

### TROUBLESHOOTING TIPS

If you are having trouble programming HomeLink®, here are some of the most common solutions:

- Replace the battery in the garage door opener hand-held transmitter.

- Push the LEARN button on the garage door opener to complete the training for a rolling code.
- Did you unplug the device for programming and remember to plug it back in?

If you have any problems, or require additional assistance, please call toll-free 1-800-355-3515 or visit HomeLink.com.

### WARNING!

- Vehicle exhaust contains carbon monoxide, a dangerous gas. Do not run your vehicle in the garage while programming the transmitter. Exhaust gas can cause serious injury or death.
- Your motorized door or gate will open and close while you are programming the universal transmitter. Do not program the transmitter if people, pets or other objects are in the path of the door or gate. Only use this transmitter with a garage door opener that has a “stop and reverse” feature as required by Federal safety standards. This includes most garage door opener models manufactured after 1982. Do not use a garage door opener without these safety features.

## PARKING ASSISTANCE

### PARKSENSE FRONT/REAR PARK ASSIST SYSTEM

Scan this QR code to learn more about the front and rear park assist system.



The ParkSense sensors located in the rear fascia/bumper and (if equipped) in the front fascia/bumper, monitor the area in front and behind the vehicle that is within the sensors' field of view. These sensors detect the presence of any obstacles and warn the driver through an acoustic signal and visual indications, which will be displayed on the instrument cluster display.

Enabling And Disabling ParkSense: push the ParkSense button located to the left of the headlight switch.



### ParkSense On/Off Switch

The driver can select the type of warning they would like to be displayed through the radio system. To access the function on the main menu, select in the following order: Driver Assistance, ParkSense, Mode, Sound and Display.

### WARNING!

Drivers must be careful when backing up even when using the ParkSense system. Always check carefully behind your vehicle, and be sure to check for pedestrians, animals, other vehicles, obstructions, or blind spots before backing up. You are responsible for the safety of your surroundings and must continue to pay attention while backing up. Failure to do so can result in serious injury or death.

### CAUTION!

- The ParkSense system is only a parking aid and it is unable to recognize every obstacle, including small obstacles. Parking curbs might be temporarily detected or not detected at all. Obstacles located above or below the sensors will not be detected when they are in close proximity.
- The vehicle must be driven slowly when using the ParkSense system in order to be able to stop in time when an obstacle is detected. It is recommended that the driver looks over his/her shoulder when using the ParkSense system.

## ELECTRIC PARK BRAKE (EPB)

Scan this QR code to learn more about the electric park brake.



Your vehicle is equipped with an EPB system that offers simple operation, and some additional features that make the parking brake more convenient and useful. The parking brake is primarily intended to prevent the vehicle from rolling while parked. Before leaving the vehicle, make sure that the parking brake is applied.

Also, be certain to leave the transmission in PARK.



### EPB Switch

The EPB can be engaged in two ways:

- Manually, by pulling the switch on the center console.
- Automatically, in "Safe Hold" or "Auto Park Brake" conditions.

### Engaging The EPB Manually

Briefly pull the switch located on the center console to manually engage the EPB when the vehicle is stationary.

With the EPB engaged, the Brake Warning Light on the instrument cluster display and the switch will illuminate.

### CAUTION!

With the Electric Park Brake Warning Light on, some functions of the EPB are deactivated. In this case the driver is responsible for engaging the EPB manually to ensure the vehicle is safely and properly parked.

### WARNING!

Driving the vehicle with the parking brake engaged, or repeated use of the parking brake to slow the vehicle may cause serious damage to the brake system. Be sure the parking brake is fully disengaged before driving; failure to do so can lead to brake failure and a collision.

#### Disengaging The EPB Manually

In order to manually release the parking brake, the ignition should be in the ACC position. Press the brake pedal, and then push the switch on the center console briefly.

After disengaging the EPB, the Brake Warning Light on the instrument cluster display and the light on the switch will turn off.

### WARNING!

- Never use the PARK position as a substitute for the parking brake. Always apply the

*(Continued)*

### WARNING!

parking brake fully when parked to guard against vehicle movement and possible injury or damage.

- When exiting the vehicle, always turn the ignition OFF, secure the key fob, and lock your vehicle.
- Never leave children alone in a vehicle, or with access to an unlocked vehicle. Allowing children to be in a vehicle unattended is dangerous for a number of reasons. A child or others could be seriously or fatally injured. Children should be warned not to touch the parking brake, brake pedal or the gear selector.
- Do not leave the key fob in or near the vehicle, or in a location accessible to children, and do not leave a vehicle equipped with a keyless ignition system in the ON/RUN position. A child could operate power windows, other controls, or move the vehicle.
- Be sure the parking brake is fully disengaged before driving; failure to do so can lead to brake failure and a collision.
- Always fully apply the parking brake when leaving your vehicle, or it may roll and cause damage or injury. Also be certain to leave the transmission in PARK. Failure to do so

*(Continued)*

### WARNING!

may allow the vehicle to roll and cause damage or injury.

## PERFORMANCE FEATURES


### ALFA DNA SYSTEM

This vehicle is equipped with an Alfa DNA system selector (located on the center console). There are four modes of operation to be selected according to driving style and road conditions:



**Alfa DNA System Selector**

- d = Dynamic (sports driving).
- n = Natural (driving in normal conditions).

- a = Advanced Efficiency (ECO driving for maximum fuel savings).
- RACE = track race driving (if equipped).
-  = Adjusts the calibration of the active suspension (if equipped).

Just rotate the selector to the desired mode to activate. When the engine is stopped, the selector will return to “n” Natural Mode.

#### WARNING!

In Race and Dynamic Mode, the sensitivity of the accelerator pedal increases considerably. Consequently, driving is less fluid and comfortable. The driver must ensure full control of the vehicle at all times to avoid a collision.

## ALFA ACTIVE SUSPENSION (AAS) — IF EQUIPPED

Your vehicle has two types of suspension calibration to choose from: a sportier or a more comfortable one.

By pushing the button, the system changes the shock absorber calibration.



**Alfa Active Suspension Button**

## EXTERIOR OVERVIEW



1 – Exterior Camera Locations ⇨ page 32

2 – Liftgate Release Button ⇨ page 34

3 – Refueling the vehicle ⇨ page 34

4 – Emergency Tow Hook ⇨ page 44

5 – Hands-Free Liftgate ⇨ page 34

## EXTERIOR CAMERA VIEWS

### BACK UP CAMERA

The Rear Back Up Camera allows you to see an on-screen image of the rear surroundings of the vehicle whenever the gear selector is put into REVERSE.

#### Camera Activation/Deactivation

To activate the Rear Back Up Camera features, select "Driver Assistance" from the Main Menu of the radio system. Under Driver Assistance, Rear Back Up Camera features can be selected:

1. View
2. Camera Delay
3. Camera Guidelines

#### WARNING!

Drivers must be careful when backing up even when using the ParkView Rear Back Up Camera. Always check carefully behind your vehicle, and be sure to check for pedestrians, animals, other vehicles, obstructions, or blind spots before backing up. You are responsible for the safety of your surroundings and must continue to pay attention while backing up. Failure to do so can result in serious injury or death.

#### CAUTION!

- To avoid vehicle damage, ParkView should only be used as a parking aid. The ParkView camera is unable to view every obstacle or object in your drive path. You remain responsible at all times for parking safely while using the ParkView camera.
- To avoid vehicle damage, the vehicle must be driven slowly when using ParkView to be able to stop in time when an obstacle is seen. It is recommended that the driver look frequently over his/her shoulder when using ParkView.

## HOOD

### TO OPEN THE HOOD


To open the hood, two latches must be released.

1. Pull the hood release lever located underneath the driver's side of the instrument panel.



**Hood Release Lever**

2. Move to the outside of the vehicle. The safety latch release lever is located behind the front edge of the hood at the center. Lift the hood slightly and reach in at the center of the hood with a palm facing the ground. Once contact is made with the safety latch release lever, push it to the left to fully release the hood.



**Safety Latch**

3. Raise the hood completely. The operation is assisted by the addition of two gas props which hold it in the open position.

**NOTE:**

- Vehicle must be at a stop and the gear selector must be in PARK.
- Before lifting the hood, check that the wiper arms are not in motion and not in the lifted position.
- While lifting the hood, use both hands.

**WARNING!**

Before opening the hood, apply the Electric Park Brake (EPB) and place the gear selector in PARK. Otherwise the vehicle may roll and cause damage, serious injury, or death.

**CAUTION!**

Do not tamper with the gas props.

**CLOSING THE HOOD**

To close, lower the hood to approximately 16 inches (40 cm) from the engine compartment then let it drop. Make sure that the hood is completely closed and fully latched.

**WARNING!**

Be sure the hood is fully latched before driving your vehicle. If the hood is not fully latched, it could open when the vehicle is in motion and block your vision. Failure to follow this warning could result in serious injury or death.

**LIFTGATE**

**LIFTGATE RELEASE BUTTON**

You can open your liftgate in any of the following ways:

- Pressing the liftgate release button on the key fob twice within five seconds
- Pushing the external liftgate release switch (when the liftgate is unlocked)
- Lifting the interior liftgate release button on the driver's door panel trim



**External Liftgate Release Switch**

**WARNING!**

Driving with the liftgate open can allow poisonous exhaust gases into your vehicle. You and your passengers could be injured by these fumes. Keep the liftgate closed when you are operating the vehicle.

## HANDS-FREE LIFTGATE — IF EQUIPPED

You can open your Hands-Free Liftgate by kicking your leg in a straight in and out motion under the vehicle activation zone that is located below the rear license plate. Do not move your foot sideways, or in a sweeping motion, or the sensors may not detect the request.



### Hands-Free Liftgate Activation Zone

If the liftgate is already opened, kicking your leg under the activation zone will close the liftgate completely.

To operate the Hands-Free Liftgate system:

#### NOTE:

- If the doors are locked, the system must detect the key fob near the liftgate.
- If the doors are unlocked, the system does not have to detect the key fob near the liftgate.

- Go to the rear of the vehicle, in the center and about 3 feet (1m) from the liftgate.
- Move your foot under the bumper, simulating a kick. When you have completed this movement, withdraw your leg. To activate the liftgate, both sensors must detect your leg.

You can activate/deactivate the Hands-Free Liftgate on the radio system by pushing the MENU button to select the Main menu, and selecting the following items: Settings, Doors And Locks, Automatic Liftgate Opening.

#### WARNING!

- Driving with the liftgate open can allow poisonous exhaust gases into your vehicle. You and your passengers could be injured by these fumes. Keep the liftgate closed when you are operating the vehicle.
- If you are required to drive with the liftgate open, make sure that all windows are closed, and the climate control blower switch is set at high speed. Do not use the recirculation mode.
- During power operation, personal injury or cargo damage may occur. Ensure the liftgate travel path is clear. Make sure the liftgate is closed and latched before driving away.

*(Continued)*

#### WARNING!

- Personal injury or cargo damage may occur if caught in the path of the liftgate. Make sure the liftgate path is clear before activating the liftgate.

#### CAUTION!

The Hands-Free Liftgate can be turned off manually in the radio system to avoid unintentional activation.

## REFUELING THE VEHICLE

Stop the engine before refueling.

The fuel filler door is unlocked when the central door locking system is unlocked. It is automatically locked when the central locking system is applied.

You can push and release the unlock button on the key fob twice within one second to unlock the fuel door.

1. Open fuel filler door by pushing on the point shown by the arrow.



### Fuel Door

2. Remove the fuel filler cap.
3. Insert the fuel nozzle fully into the filler pipe.
4. When the fuel nozzle "clicks" or shuts off, before removing the nozzle, wait for at least 10 seconds in order for the fuel to flow inside the tank.
5. Remove the fuel filler nozzle, tighten the gas cap about a quarter turn until you hear one click. This is an indication that the cap is properly tightened.

### WARNING!

- Never have any smoking materials lit in or near the vehicle when the fuel door is open or the tank is being filled.
- Never add fuel when the engine is running. This is in violation of most state and federal fire regulations and may cause the Malfunction Indicator Light (MIL) to turn on.
- A fire may result if fuel is pumped into a portable container that is inside of a vehicle. You could be burned. Always place fuel containers on the ground while filling.

### CAUTION!


To avoid fuel spillage and overfilling, do not "top off" the fuel tank after filling.

### Emergency Fuel Door Release

In the event of an emergency, the fuel filler door can be opened from inside the liftgate.

#### Models With Compact Spare Tire

1. Open the liftgate and lift up the load floor.
2. Unlock the locking device and remove the compact spare tire to reach the emergency opening cable on the side of the fuel door.
3. Pull the cable 1 to release the fuel door lock.




### Release Cable

4. Open the fuel door by pushing it.

#### Models Without Compact Spare Tire

1. Open the liftgate and lift up the load floor.
2. Lift up the cover to reach the emergency opening cable on the side of the fuel door.

3. Pull the cable 2 to release the fuel door lock.



**Cargo Box opened**

4. Open the fuel door by pushing it.

## SOS AND ASSIST SYSTEM — IF EQUIPPED



SOS Emergency Call Button

### Making an SOS Call

1. Push and hold the SOS Emergency Call button for a few seconds.

**NOTE:**

In case the SOS Call button is pushed in error, there will be a 10 second delay before the SOS Call system initiates a call to an SOS operator. To cancel the call connection, push the SOS Emergency Call button again.

2. The LED, located next to the SOS button, will blink once and then stay on indicating a call has been placed.

3. Once a connection between the vehicle and an SOS operator is made, the SOS Call system may transmit the following important vehicle information to an SOS operator:
  - Indication that the occupant placed an SOS Emergency Call.
  - The Vehicle Identification Number (VIN).
  - The last known GPS coordinates of the vehicle
4. You should be able to speak with the SOS operator through the vehicle audio system to determine if additional assistance is needed.

### WARNING!

ALWAYS obey traffic laws and pay attention to the road. ALWAYS drive safely with your hands on the steering wheel. You have full responsibility and assume all risks related to the use of the features and applications in this vehicle. Only use the features and applications when it is safe to do so. Failure to do so may result in an accident involving serious injury or death.

**NOTE:**

- You will then be able to speak with the emergency service operator to determine if additional help is needed.

- If you have not subscribed to the SOS service or if the service is not available or has expired, the Connect system will display a dedicated screen when the button is pressed informing you to contact the national emergency number 9-1-1 (the respective graphic button will be displayed to make the call if you have connected your mobile phone via Bluetooth®. The call to the national emergency number 9-1-1 will be made via the mobile phone by pressing red graphic button shown on the Connect system display.

### WARNING!

- If anyone in the vehicle could be in danger (e.g., fire or smoke is visible, dangerous road conditions or location), do not wait for voice contact from an Emergency Services Agent. All occupants should exit the vehicle immediately and move to a safe location.
- Never place anything on or near the vehicle's operable network and GPS antennas. You could prevent operable network and GPS signal reception, which can prevent your vehicle from placing an emergency call. An operable network and GPS signal reception is required for the SOS Call system to function properly.

*(Continued)*

### WARNING!

- The SOS Call system is embedded into the vehicle's electrical system. Do not add aftermarket electrical equipment to the vehicle's electrical system. This may prevent your vehicle from sending a signal to initiate an emergency call. To avoid interference that can cause the SOS Call system to fail, never add aftermarket equipment (e.g., two-way mobile radio, CB radio, data recorder, etc.) to your vehicle's electrical system or modify the antennas on your vehicle. IF YOUR VEHICLE LOSES BATTERY POWER FOR ANY REASON (INCLUDING DURING OR AFTER AN ACCIDENT), THE SOS FEATURES, APPS AND SERVICES, AMONG OTHERS, WILL NOT OPERATE.
- Modifications to any part of the SOS Call system could cause the air bag system to fail when you need it. You could be injured if the air bag system is not there to help protect you.
- ALWAYS obey traffic laws and pay attention to the road. ALWAYS drive safely with your hands on the steering wheel. You have full responsibility and assume all risks related to the use of the features and applications in this vehicle. Only use the features and applications when it is safe to do so. Failure

*(Continued)*

### WARNING!

to do so may result in an accident involving serious injury or death.

- Ignoring the overhead console light could mean you will not have SOS Call services. If the overhead console light is illuminated, have an authorized dealer service the SOS Call system immediately.
- The Occupant Restraint Control module turns on the Air Bag Warning Light on the instrument panel if a malfunction in any part of the system is detected. If the Air Bag Warning Light is illuminated, have an authorized dealer service the Occupant Restraint Control system immediately.

## JACKING AND TIRE CHANGING — IF EQUIPPED

### PREPARATIONS FOR JACKING

1. Park on a firm, level surface (avoid ice or slippery areas).

### WARNING!

Do not attempt to change a tire on the side of the vehicle close to moving traffic. Pull far enough off the road to avoid being

*(Continued)*


### WARNING!

hit when operating the jack or changing the wheel.

2. Turn on the Hazard Warning Flashers.



3. Apply the Electric Park Brake.
4. Place the ignition to the OFF mode.
5. Block both the front and rear of the wheel diagonally opposite of the jacking position. For example, if changing the left rear tire, block the right front wheel.



**Wheel Blocked**

**NOTE:**

- Passengers should not remain in the vehicle when the vehicle is being raised or lifted.
- Do not attempt to change a tire on the side of the vehicle close to moving traffic. Pull far enough off the road to avoid being hit when operating the jack or changing the wheel.

## ACCESSING THE JACK, TOOLS, AND SPARE TIRE

If equipped, the jack, tools and spare tire are located under the load floor in the rear cargo compartment.



**1 — Locking Plate**

To access the jack, tools and spare tire proceed as follows:

1. Open the liftgate and lift up the load floor using the handle.
2. Unscrew the locking plate and take out the compact spare tire and the air compressor.
3. Pull upward to remove the jack.

## JACKING INSTRUCTIONS

**WARNING!**

Carefully follow these tire changing warnings to help prevent personal injury or damage to your vehicle:

- Always park on a firm, level surface as far from the edge of the roadway as possible before raising the vehicle.
- Turn on the Hazard Warning Flashers.
- Apply the parking brake firmly and set the transmission in PARK.
- Block the wheel diagonally opposite the wheel to be raised.
- Never start or run the engine with the vehicle on a jack.
- Do not let anyone sit in the vehicle when it is on a jack.
- Do not get under the vehicle when it is on a jack. If you need to get under a raised

*(Continued)*

**WARNING!**

vehicle, take it to a service center where it can be raised on a lift.

- Only use the jack in the positions indicated and for lifting this vehicle during a tire change.
- If working on or near a roadway, be extremely careful of motor traffic.
- To assure that spare tires, flat or inflated, are securely stowed, spares must be stowed with the valve stem facing the ground.

1. Remove the jack, wheel bolt wrench and spare tire.
2. Remove the damaged wheel by using the wheel wrench to loosen the bolts by one turn.
3. Position the jack under the vehicle, near the wheel to be changed, taking care not to damage the plastic body panel.

4. Lift the extension lever on the wrench.




**Jacking Location**



**Jacking Location**

5. Rotate the extension lever clockwise until the round pin on the jack engages in the hole of the vehicle located about 6 inches (15 cm) from the outside edge of the body.



**Jacking Locations**

**CAUTION!**

Do not attempt to raise the vehicle by jacking on locations other than those indicated in the Jacking Instructions for this vehicle.

6. Raise the vehicle by turning the jack screw clockwise, using the swivel wrench. Raise the vehicle only until the tire just clears the surface and enough clearance is obtained to install the compact spare tire. Minimum tire lift provides maximum stability.

**WARNING!**

Raising the vehicle higher than necessary can make the vehicle less stable. It could

*(Continued)*

**WARNING!**

slip off the jack and hurt someone near it. Raise the vehicle only enough to remove the tire.

7. Remove the five wheel bolts and take the wheel off.
8. Fit the compact spare tire by inserting the first wheel bolt for two threads into the hole closest to the valve.

**CAUTION!**

Be sure to mount the spare tire with the valve stem facing outward. The vehicle could be damaged if the spare tire is mounted incorrectly.

9. Take the wheel wrench and tighten the wheel bolts.
10. Inflate the compact spare tire by removing the cap from its inflation valve and screwing on the compressor inflation hose fitting.
11. Inflate the compact spare
12. Operate the wheel wrench on the jack to lower the vehicle.
13. Remove the jack.
14. Use the wheel wrench to fully tighten the bolts, passing alternately from one bolt to the diagonally opposite one.

### WARNING!

To avoid the risk of forcing the vehicle off the jack, do not tighten the wheel nuts fully until the vehicle has been lowered. Failure to follow this warning may result in serious injury.

### WARNING!

A loose tire or jack thrown forward in a collision or hard stop could endanger the occupants of the vehicle. Always stow the jack parts and the spare tire in the places provided. Have the deflated (flat) tire repaired or replaced immediately.

## TIRE SERVICE KIT — IF EQUIPPED

Scan this QR code to learn more about Tire Service Kit.



The Tire Service Kit includes:

- Sealant cartridge containing the sealing fluid.
- Filler tube.

- Adhesive label with the writing "Max. 50 mph (80 km/h)", to be attached in a position easily visible to the driver (e.g. on the dashboard) after repairing the tire.
- Air compressor, complete with pressure gauge and connectors.
- An instruction pamphlet for reference and correct use of the Tire Service Kit, which must be then given to the personnel dealing with the sealant-treated tire.
- A pair of protective gloves (if equipped).
- Adapters for inflating different elements.

## JUMP STARTING

If your vehicle has a discharged battery, it can be jump started using a set of jumper cables and a battery in another vehicle, or by using a portable battery booster pack. Jump starting can be dangerous if done improperly, so please follow the procedures in this section carefully.

### WARNING!

Do not attempt jump starting if the battery is frozen. It could rupture or explode and cause personal injury.

### CAUTION!

Do not use a portable battery booster pack or any other booster source with a system voltage greater than 12 Volts or damage to the battery, starter motor, alternator or electrical system may occur.


### NOTE:

When using a portable battery booster pack, follow the manufacturer's operating instructions and precautions.

## PREPARATIONS FOR JUMP STARTING

Your vehicle is equipped with remote battery connection posts for jump starting.

The remote posts of the battery for jump starting can be found inside the engine compartment. The remote positive (+) post is located at the rear of the engine compartment, which can be accessed by removing the cowl cover, and opening the spring loaded protective flap. The remote negative (-) post is an exposed stud, positioned next to the passenger side hood lock on the upper frame rail.



### Remote Battery Posts

See the following steps to prepare for jump starting:

1. Firmly apply the park brake, and cycle the ignition to OFF.
2. Turn off all electrical features in the vehicle.
3. If using another vehicle to jump start the battery, park the vehicle within the jumper cables reach, set the parking brake and make sure the ignition is OFF.

### WARNING!

- Do not allow vehicles to touch each other as this could establish a ground connection and personal injury could result.

*(Continued)*

### WARNING!

- Take care to avoid the radiator cooling fan whenever the hood is raised. It can start anytime the ignition switch is ON. You can be injured by moving fan blades.
- Remove any metal jewelry such as rings, watch bands and bracelets that could make an inadvertent electrical contact. You could be seriously injured.
- Batteries contain sulfuric acid that can burn your skin or eyes and generate hydrogen gas which is flammable and explosive. Keep open flames or sparks away from the battery.

## JUMP STARTING PROCEDURE

### WARNING!

Failure to follow this jump starting procedure could result in personal injury or property damage due to battery explosion.

### CAUTION!

Failure to follow these procedures could result in damage to the charging system of the booster vehicle or the discharged vehicle.

### Connecting The Jumper Cables

1. Connect the positive (+) end of the jumper cable to the positive (+) post of the discharged vehicle.
2. Connect the opposite end of the positive (+) jumper cable to the positive (+) post of the booster battery.
3. Connect the negative (-) end of the jumper cable to the negative (-) post of the booster battery.
4. Connect the opposite end of the negative (-) jumper cable to the remote negative (-) post of the discharged vehicle.

### WARNING!

Do not connect the jumper cable to the negative (-) post of the discharged battery. The resulting electrical spark could cause the battery to explode and could result in personal injury.

5. Start the engine in the vehicle that has the booster battery, let the engine idle a few minutes, and then start the engine in the vehicle with the discharged battery.
6. Once the engine is started, follow the disconnecting procedure.

## Disconnecting The Jumper Cables

1. Disconnect the negative (-) end of the jumper cable from the remote negative (-) post of the vehicle with the discharged battery.
2. Disconnect the opposite end of the negative (-) jumper cable from the negative (-) post of the booster battery.
3. Disconnect the positive (+) end of the jumper cable from the positive (+) post of the booster battery.
4. Disconnect the opposite end of the positive (+) jumper cable from the remote positive (+) post of the vehicle with the discharged battery, and reinstall the protective cap.

### CAUTION!

Accessories plugged into the vehicle power outlets draw power from the vehicle's battery, even when not in use (i.e., cellular devices, etc.). Eventually, if plugged in long enough without engine operation, the vehicle's battery will discharge sufficiently to degrade battery life and/or prevent the engine from starting.

If frequent jump starting is required to start your vehicle, you should have the battery and charging system inspected at an authorized dealer.

## IF YOUR ENGINE OVERHEATS

If the vehicle is overheating, it will need to be serviced by an authorized dealer.

Potential signs of vehicle overheating:

- Temperature gauge is at HOT (H)
- Strong smell of coolant
- White smoke coming from engine or exhaust
- Coolant bottle coolant has bubbles present

### WARNING!

You or others can be badly burned by hot engine coolant (antifreeze) or steam from your radiator. If you see or hear steam coming from under the hood, do not open the hood until the radiator has had time to cool. Never try to open a cooling system pressure cap when the radiator or coolant bottle is hot.

If the temperature gauge is moving towards or close to the HOT (H) position, you can reduce the potential for overheating by taking the appropriate action.

- On highways — slow down.
- In city traffic — while stopped, place the transmission in NEUTRAL (N), but do

not increase the engine idle speed while preventing vehicle motion with the brakes.

- Turn off the Air Conditioner (A/C). The A/C system adds heat to the engine cooling system and turning the A/C off can help remove this heat.
- You can also turn the temperature control to maximum heat, and the blower control to high. This allows the heater core to act as a supplement to the radiator and aids in removing heat from the engine cooling system.

### CAUTION!

Driving with a hot cooling system could damage your vehicle. If the temperature gauge reads H, pull over and stop the vehicle. Idle the vehicle with the air conditioner turned off until the pointer drops back into the normal range. If the pointer remains on the H and you hear continuous chimes, turn the engine off immediately and call for service.

## TOWING A DISABLED VEHICLE

This section describes procedures for towing a disabled vehicle using a commercial towing service.

TOWING CONDITION	WHEELS OFF THE GROUND	ALL-WHEEL DRIVE (AWD)
Flat Tow	NONE	NOT ALLOWED
Dolly Tow	REAR	NOT ALLOWED
	FRONT	NOT ALLOWED
On Trailer	ALL	BEST METHOD
When towing your vehicle, always follow applicable state and provincial laws. Contact state and provincial Highway Safety offices for additional details.		

Proper towing or lifting equipment is required to prevent damage to your vehicle. Use only tow bars and other equipment designed for this purpose, following equipment manufacturer's instructions. Use of safety chains is mandatory. Attach a tow bar or other towing devices to main structural members of the vehicle, not to fascia/bumper or associated brackets. State and local laws regarding vehicles under tow must be observed.

**NOTE:**

- You must ensure that the Auto Park Brake feature is disabled before towing this vehicle to avoid inadvertent Electric Park Brake engagement. The Auto Park Brake feature is enabled or disabled via the customer programmable features in the Information and Entertainment Settings.
- Vehicles with a discharged battery, or total electrical failure when the Electric Park Brake (EPB) is engaged, will need a wheel dolly or

jack to raise the rear wheels off the ground when moving the vehicle onto a flatbed.

If you must use the accessories (wipers, defrosters, etc.) while being towed, the ignition must be in the ON/RUN mode.

Note that the Safehold feature will engage the Electric Park Brake whenever the driver's door is opened (if the battery is connected, ignition is ON, transmission is not in PARK, and brake pedal is released). If you are towing this vehicle with the ignition in the ON/RUN mode, you must manually disable the Electric Park Brake each time the driver's door is opened by pressing the brake pedal and then releasing the EPB.

If the vehicle's battery is discharged, instructions on shifting the automatic transmission out of PARK so that the vehicle can be moved ➡ page 44.

**CAUTION!**

- Do not use sling-type equipment when towing. Vehicle damage may occur.
- When securing the vehicle to a flatbed truck, do not attach to front or rear suspension components. Damage to your vehicle may result from improper towing.
- Ensure that the Electric Park Brake is released, and remains released, while being towed.
- Do not use a fascia/bumper mounted clamp-on tow bar on your vehicle. The fascia/bumper face bar will be damaged.

**TOWING IN AN EMERGENCY**

This section describes procedures for towing a disabled vehicle using a commercial towing service.

The operators of the assistance vehicle must be informed with regard to the vehicle's minimum height from ground in order to avoid contact between the ends of the fascia/bumper with the equipment of the breakdown truck.

### Tow Eye Usage

Proceed as follows to use the tow eye:

- Unhook the cap on the front grille or rear fascia/bumper (if equipped), pushing on the upper part.
- Remove the tow eye from its housing in the luggage compartment and carefully clean the threaded housing on the vehicle before using it.
- Tighten the vehicle's tow eye in place (about 11 turns).



**Front Tow Eye Cap Location**



**Rear Tow Eye Cap Location**

### Tow Eye Usage Precautions

#### CAUTION!

- The tow eye must only be used for roadside emergencies. Use with an appropriate device in accordance with highway code (a rigid bar or rope) to maneuver the vehicle in preparation for transport via a tow truck.
- The tow eye must not be used to move the vehicle off the road or where there are obstacles.
- Do not use the tow eyes for tow truck hookup or highway towing.
- Do not use the tow eye to free a stuck vehicle.

*(Continued)*

#### CAUTION!

- Damage to your vehicle may occur if these guidelines are not followed.


#### WARNING!

Stand clear of vehicles when pulling with tow eyes.

- Do not use a chain with a tow eye. Chains may break, causing serious injury or death.
- Do not use a tow strap with a tow eye. Tow straps may break or become disengaged, causing serious injury or death.
- Failure to follow proper tow eye usage may cause components to break resulting in serious injury or death.

## ENGINE COMPARTMENT OVERVIEW

### 2.0L ENGINE



1 — Engine Coolant Reservoir Cap  
2 — Brake Fluid Reservoir Access Cover

3 — Windshield/Headlights Washer Fluid Reservoir  
4 — Engine Oil Filler Cap

5 — Intercooler Coolant Reservoir Cap

## FLUID CAPACITIES

	US	Metric
<b>Fuel (Approximate)</b>		
All Engines	16.9 gal	64 L
<b>Engine Oil With Filter</b>		
2.0L Engine	5.5 qt	5.2 L
<b>Cooling System*</b>		
2.0L Engine – Engine Cooling System	2.3 gal	8.8 L
2.0L Engine – Intercooler	1.4 gal	5.25 L
* Includes heater and coolant recovery bottle filled to MAX level.		

## ENGINE FLUIDS AND LUBRICANTS

We recommend using the following fluids and lubricants:

Component	Fluid, Lubricant, or Genuine Part
Engine Coolant – 2.0L Engine	We recommend using Mopar® Antifreeze/Coolant 10 Year/150,000 Miles (240,000 Kilometers) Formula OAT (Organic Additive Technology) meeting the requirements of the manufacturer Material Standard MS.90032.
Engine Oil – 2.0L Engine	We recommend using Mopar® API SP/GF-6A Certified SAE 0W-30 Full Synthetic Engine Oil which meets the requirements of the manufacturer Material Standard MS-13340. Equivalent full synthetic 0W-30 API SP engine oil can be used but must have the API Donut trademark.
	<b>CAUTION!</b>
	<b>Failure to use the recommended API SP/GF-6A or equivalent oil can cause engine damage not covered by the vehicle warranty.</b>
Fuel Selection – 2.0L Engine	87 Octane (R+M)/2 Method, 0-15% ethanol.

## CHASSIS FLUIDS AND LUBRICANTS

We recommend using the following chassis fluid and lubricants:

Component	Fluid, Lubricant, or Genuine Part
Automatic Transmission	ZF 8HP 50 - Synthetic ATF
Differential And Reduction Units RDU 195; RDU 230-LSD; RDU 210-eLSD; RDU 210/215-LSD / 2.0L Engine	SAE 75W-85 Synthetic ATF FPW9.55550-DA9
AWD System FAD Transfer Case / 2.0L Engine	SAE 75W-80 APL GL-5 Synthetic lubricant FPW9.55550-DA10
AWD System Transfer Case	SAE 75W Synthetic lubricant FPW9.55550-DA11
Brake Fluid	We recommend using Mopar® DOT 4 (Tutela TOP EVO).

# SERVICING AND MAINTENANCE

## SCHEDULED SERVICING

Correct servicing is crucial for guaranteeing a long life for the vehicle under the best conditions.

For this reason, Alfa Romeo has planned a series of checks and services for your vehicle at fixed intervals based on distance and time, as described in the Scheduled Servicing Plan.

Before each service, follow the instructions in the Scheduled Servicing Plan (e.g. periodically check level of fluids, tire pressure, etc.).

Scheduled Servicing is offered by an authorized dealer according to a set time schedule. If, during each operation, in addition to the ones scheduled, the need arises for further replacements or repairs, these may be carried out with the owner's explicit consent only.

### NOTE:

Scheduled Servicing intervals are required by the manufacturer. Failure to have them carried out may invalidate the New Vehicle Limited Warranty.

Inform an authorized dealer of any small operating irregularities without waiting for the next service.

## Periodic Checks

Every month or every 620 miles (1,000 km) or before long trips check and, if necessary, top up fluids:

- Check the engine oil level
- Check the operation of the interior and exterior lights
- Check the 12V battery terminals, cables and connections
- Check the brake pads, rotors, brake operation and fluid level
- Check the steering, suspension, axle boots and chassis components
- Check the wiper and washer operation, wiper blades and solvent reservoir
- Check the tire pressure
- Check the cooling system reservoir/s

Oil consumption of the engine depends on conditions and driving style. For this reason, the engine oil level must be checked every 1,860 miles (3,000 km), and top up if necessary.

## Severe Duty All Models

Change engine oil at 4,000 miles (6,500 km) if the vehicle is operated in a dusty and off-road environment or is operated predominately at idle

or only very low engine RPM. This type of vehicle use is considered Severe Duty.

## Maintenance Plan

Refer to the Maintenance Plan for the required maintenance intervals.

At Every Oil Change Interval As Indicated By Oil Change Indicator System:
Change oil and filter.
Rotate the tires at the first sign of irregular wear, even if it occurs before the oil indicator system turns on.
Inspect battery and clean and tighten terminals as required.
Inspect the CV/Universal joints.
Inspect brake pads, shoes, rotors, drums, and hoses.
Inspect engine cooling system protection and hoses.
Inspect exhaust system.
Inspect engine air cleaner filter if using in dusty or off-road conditions, replace the engine air cleaner filter if necessary.

### NOTE:

Using white lithium grease, lubricate the door hinge roller pivot joints twice a year to prevent premature wear.

## WARNING!

- You can be badly injured working on or around a motor vehicle. Do only service work for which you have the knowledge and the right equipment. If you have any doubt about your ability to perform a service job, take your vehicle to a competent mechanic.
- Failure to properly inspect and maintain your vehicle could result in a component malfunction and affect vehicle handling and performance. This could cause an accident.

### Every 10,000 Miles (16,000 Km)

- Change engine oil and replace oil filter<sup>1</sup>
- Check battery charge status with the proper instrument
- Check tire condition/wear and adjust pressure, if necessary. Check the tire repair kit recharge condition and expiration date

- Check operation of lighting system (headlights, direction indicators, hazard warning lights, trunk lid, passenger compartment, glove compartment, instrument panel warning lights, etc.)
- Check and, if necessary, top up fluid levels
- Check engine control system operation (via diagnostic tool) and, if equipped, engine oil degradation<sup>2</sup>
- Check position/wear of front windshield wiper blade
- Check operation of the windshield wiper/washer system and adjust nozzles, if necessary
- Visually inspect conditions and wear of front/rear disc brake pads and operation of pad wear indicators
- Visually inspect the condition and tensioning of the accessory drive belt(s)
- Replace the additional fuel filter (if equipped)

- Replace cabin air filter<sup>3</sup>

### Every 20,000 Miles (32,000 Km)

- Visually inspect conditions of: exterior bodywork, underbody protection, pipes and hoses (exhaust, fuel system, brakes), rubber elements (sleeves, bushes, etc.)
- Check cleanliness of hood and luggage compartment locks, cleanliness and lubrication of linkage

- Replace cabin air filter<sup>3</sup>

### Every 30,000 Miles (48,000 Km)

- Replace engine air cleaner filter<sup>3</sup>

### Every 50,000 Miles (80,000 Km)

- SOS backup battery replacement (if equipped)<sup>4</sup>

### Every 60,000 Miles (96,000 Km)

- Spark plug replacement<sup>5</sup>

<sup>1</sup> The actual interval for changing engine oil and replacing the engine oil filter depends on the vehicle usage conditions and is signaled by the warning light or message in the instrument panel. In all cases, never exceed 1 year/10,000 miles (16,000 km).

<sup>2</sup> If oil degradation ratio (data collectible from diagnostic device) is more than 80% (oil quality less than 20%), engine oil and filter replacement is recommended.

<sup>3</sup> If the vehicle is used in dusty areas, the cabin and/or engine air filter must be replaced every 10,000 miles (16,000 km).

<sup>4</sup> The SOS backup battery must be replaced every five years, regardless of mileage.

<sup>5</sup> The spark plug change interval is 60,000 miles for NAFTA market or 60,000 km outside NAFTA. Yearly intervals do not apply.

### Every 80,000 Miles (128,000 Km)

- Replace transfer case oil (AWD models only)

### Every 150,000 Miles (240,000 Km)

- Change engine coolant
- Replace accessory drive belt(s)

## OIL CHANGE RESET

- Your vehicle is equipped with an engine oil change indicator system. The change oil message will display in the instrument cluster display for five seconds after a single chime has sounded, to indicate the next scheduled oil change. The engine oil change indicator system is duty cycle based, which means the engine oil change interval may fluctuate, depending upon your personal driving style.
- Unless reset, this message will continue to display each time the ignition is cycled to the ON/RUN position.

To reset the oil change indicator after performing the scheduled maintenance, refer to the following procedure:

1. Without pressing the brake pedal, push the ENGINE START/STOP button and cycle the ignition to the ON/RUN position (do not start the engine).
2. Fully press the accelerator pedal, slowly, three times within ten seconds.

3. Cycle the ignition to the OFF position.

### NOTE:


If the indicator message illuminates when you start the vehicle, the oil change indicator system did not reset. If necessary, repeat this procedure.

## ENGINE BREAK-IN RECOMMENDATIONS

A long break-in period is not required for the engine and drivetrain (transmission and axle) in your vehicle.

Drive moderately during the first 300 miles (500 km). After the initial 60 miles (100 km), speeds up to 50 or 55 mph (80 or 90 km/h) are desirable.

While cruising, brief full-throttle acceleration within the limits of local traffic laws contributes to a good break-in. You should avoid wide-open throttle acceleration in low gear as it can be detrimental.

The engine oil installed in the engine at the factory is a high-quality energy conserving type lubricant. Oil changes should be consistent with anticipated climate conditions under which vehicle operations will occur. For the recommended viscosity and quality grades  page 48.

### CAUTION!

Never use Non-Detergent Oil or Straight Mineral Oil in the engine or damage may result.

## TRAILER TOWING

To maintain the New Vehicle Limited Warranty coverage, follow the requirements and recommendations in your Owner's Manual concerning vehicles used for trailer towing.

### Trailer Towing Weights (Maximum Trailer Weight Ratings)

Engine/ Transmission	Maximum GTW	Maximum Trailer TW (See Note)
2.0L Engine	3,000 lb (1,360 kg)	300 lb (136 kg)
Refer to local laws for maximum trailer towing speeds.		

The trailer tongue weight must be considered as part of the combined weight of occupants and cargo, and should never exceed the weight referenced on the Tire And Loading Information Placard.

<b>A</b>			
Alfa Active Suspension (AAS) .....	30	Selection Of Coolant (Antifreeze) .....	48
Alfa DNA System .....	29	Cruise Control (Speed Control) .....	24
Android Auto .....	11	Customer Assistance .....	5
Antifreeze (Engine Coolant) .....	48	<b>D</b>	
Automatic Headlights .....	22	Dimmer Control Switch .....	22
Automatic High Beams .....	22	Disable Vehicle Towing .....	43
Automatic Temperature Control (ATC) ....	18	<b>E</b>	
Automatic Transmission		Electrical Power Outlets .....	12
Fluid Type .....	47-49	Emergency, In Case Of	
Axle Fluid .....	47, 49	Jump Starting .....	41
<b>B</b>		Towing .....	43
Back Up Camera .....	32	Engine .....	46
Brake Fluid .....	47-49	Break-In Recommendations .....	52
<b>C</b>		Coolant (Antifreeze) .....	48
Camera .....	32	Fuel Requirements .....	48
Camera, Rear .....	32	Jump Starting .....	41
Capacities, Fuel .....	48	Oil .....	48
Caps, Filler		Oil Filler Cap .....	46
Oil (Engine) .....	46	Oil Selection .....	48
Cargo Light .....	22	Overheating .....	43
Contract, Service .....	6	Exterior Lights .....	22
Cooling System		<b>F</b>	
Cooling Capacity .....	48	Filters	
		Engine Oil .....	48
		Fluid Capacities .....	48
		Fluid, Brake .....	48
		Fog Lights .....	22
		Fuel	
		Filler Cap (Gas Cap) .....	34
		Octane Rating .....	48
		Requirements .....	48
		Tank Capacity .....	48
		<b>G</b>	
		Garage Door Opener (HomeLink®) .....	26
		Gas Cap (Fuel Filler Cap) .....	34
		<b>H</b>	
		Headlights	
		On With Wipers .....	22
		Switch .....	22
		<b>I</b>	
		Instrument Cluster .....	15
		Descriptions .....	15
		Location And Controls .....	16
		<b>J</b>	
		Jump Starting .....	41

## L

Liftgate .....	33
Hands-Free .....	34
Opening .....	33
Lights	
Cargo .....	22
Exterior .....	22
Fog .....	22
Headlights .....	22

## M

Maintenance Schedule .....	50
Manual	
Service .....	6
Media Hub .....	14
Memory Seat .....	20
Memory Settings .....	20

## N

New Vehicle Break-In Period .....	52
-----------------------------------	----

## O

Oil Change Indicator	
Reset .....	52
Oil, Engine .....	48

Capacity .....	48
Filter .....	48
Recommendation .....	48
Viscosity .....	48
Operator Manual	
Owner's Manual .....	6
Overheating, Engine .....	43

## P

Parking Brake .....	28
ParkSense System, Rear .....	27
Phone	
Pairing .....	11
Power	
Outlet (Auxiliary Electrical Outlet) .....	12
Seats .....	20

## R

Radio	
Settings .....	10
Rain Sensitive Wiper System .....	23
Rear ParkSense System .....	27

## S

Schedule, Maintenance .....	50
Seats	
Memory .....	20

Power .....	20
Selection Of Coolant (Antifreeze) .....	48
Service Assistance .....	5
Service Contract .....	6
Service Manuals .....	6
Settings .....	10
SOS Call .....	37
Speed Control (Cruise Control) .....	24
Steering	
Wheel, Voice Recognition .....	11

## T

To Open Hood .....	32
Towing .....	52
Disabled Vehicle .....	43
Towing Eyes .....	44
Traffic Sign Recognition .....	17
Trailer Towing .....	52
Transfer Case	
Fluid .....	47, 49
Transmission	
Fluid .....	47-49

## U


Uconnect System .....	10
USB .....	14

## V

Vehicle Settings .....	10
Voice Recognition System (VR) .....	11

## W

Warning Lights And Messages .....	17
Warranty Information .....	6
Windshield Washers .....	23
Wipers, Rain Sensitive .....	23
Wireless Charging Pad .....	13



The driver's primary responsibility is the safe operation of the vehicle. Driving while distracted can result in loss of vehicle control, resulting in an accident and personal injury. FCA US LLC strongly recommends that the driver use extreme caution when using any device or feature that may take their attention off the road. Use of any electrical devices, such as cellular telephones, computers, portable radios, vehicle navigation or other devices, by the driver while the vehicle is moving is dangerous and could lead to a serious accident. Texting while driving is also dangerous and should never be done while the vehicle is moving. If you find yourself unable to devote your full attention to vehicle operation, pull off the road to a safe location and stop your vehicle. Some states or provinces prohibit the use of cellular telephones or texting while driving. It is always the driver's responsibility to comply with all local laws. Vehicle images are for illustration purposes only. Actual products sold may vary.

This Owner Handbook has been prepared to help you get acquainted with your new Alfa Romeo brand vehicle and to provide a convenient reference source for common questions.

Not all features shown in this manual may apply to your vehicle. For additional information, visit [www.alfaromeousa.com](http://www.alfaromeousa.com) (USA), [www.alfaromeo.ca](http://www.alfaromeo.ca) (Canada) or your local Alfa Romeo brand dealer. This Owner Handbook is intended to familiarize you with the important features of your vehicle. Your most up-to-date Owner Handbook, Owner's Manual, Radio Instruction Manual and Warranty Booklet can be found by visiting the website on the back cover.

## DRIVING AND ALCOHOL

Drunk driving is one of the most frequent causes of accidents. Your driving ability can be seriously impaired with blood alcohol levels far below the legal minimum. If you are drinking, don't drive. Ride with a designated non-drinking driver, call a cab, a rideshare, a friend, or use public transportation.

## WARNING

Driving after drinking can lead to an accident. Your perceptions are less sharp, your reflexes are slower and your judgment is impaired when you have been drinking. Never drink and then drive.





SCAN TO DOWNLOAD  
COMPLETE OWNER'S  
MANUAL, RADIO AND  
WARRANTY MANUALS

U.S.



[alfaromeousa.com/owners/  
owners-service-manual](https://alfaromeousa.com/owners/owners-service-manual)

CANADA



[alfaromeo.ca/en/owners/  
owners-service-manual](https://alfaromeo.ca/en/owners/owners-service-manual)

©2024 FCA US LLC. All Rights Reserved. ALFA ROMEO is a registered trademark of FCA Group Marketing S.p.A., used with permission. App Store is a registered trademark of Apple Inc. Google Play Store is a registered trademark of Google.

Second Edition  
25\_GU\_OH\_EN\_USC